RC107

Regal Reading Writing Center - Assembly Guide

If parts are missing or you require assistance, please call:


1-800-267-8494 or email info@copernicused.com

Have your packing slip ready for reference

RC107_2009_B


This assembly guide provides instructions to build the Regal Reading Writing Center Check out our full line of products at www.copernicused.com

This product is meant to be assembled by an Adult.WARNINGIn its unassembled state, small parts present a hazard.
This product to be used under the direct supervision of an adult.





Before beginning, you should have:



Tips for Assembly - Using this Manual

Watch for These Helpful Symbols

This symbol denotes a 2 Person Task. For safety, please ensure that there are two people working on steps displaying this symbol

Watch for this symbol throughout the Assembly Instructions. Wherever you see it, pay close attention. The symbol denotes a step needing extra attention to ensure it is done correctly

The Star symbol highlights an advisory note

Before You Begin

- Layout and identify all of the included parts
- The hardware has been packed according to size, separate them based on those sizes
- Read the assembly instructions over once to familiarize yourself with them
- Please note that in its unassembled state, this product contains parts that can be a hazard to small children; it should be assembled by an adult
- If you have a cordless drill, a hex head driver bit has been included for use. This will help to speed up assembly. Make sure that the torque is on a low setting, to ensure the bolt head does not get stripped

As You Assemble the Unit

- Follow the steps in sequence
- Before beginning each step, find the part(s) that you need for that step
- Pay attention to the labeling on the parts, they are there to help direct you at certain stages
- The title of each step states what you will be doing. Review the text and the pictures as you build the unit

After Assembly; Before Use

- Remove the plastic film from the Whiteboard before writing on it
- Clean the Whiteboard surface well with soapy water and then rinse clean












Actual Size: You will need: (Not to Scale) Base x 2 Caster x 4

Install Casters


You should begin the installation with the brakes in the UP position

Note: The front of the Base is the end with the brake mechanism

- Press Casters firmly into the base
 - Caster will click into place
 - If necessary, place a wrench between the wheels & tap in with a rubber mallet.
- Repeat for remaining Base








Install Center Frame & Rear Frame Lower

- Use L & R stickers on the Rear Frame Lowers to help you distinguish the Left & Right side of the unit when looking at it from the Front
- Slide Center Frame into the front holes of the Base & Lower Frames into the rear holes of the Base





- Tighten bolts

Front of the Base is the end with the Brake



0







Install Front Frame Supports

- Align the end of the Left Front Frame Support marked with a Left sticker with the hole marked with a dot sticker in the Center Frame on the left side.
 - Fasten with one Bolt A & Washer D
 - Tighten bolt
- Repeat for Right side


- Ensure that the Front Frame Supports angle outward; there is a definite Left & Right, ensure that each is on the correct side






Install Tub Channels

• Identify the Top & Bottom of the Tub Channels









Install Spacers

- Align one Spacer with a set of holes on the Center Frame and lower Stretcher
 - Fasten with two Bolt A's & Washer D's
 - Tighten bolts








Build Front Frame Assembly

- Slide Whiteboard as far upwards as it will go
- Slide Whiteboard Channel up to the bottom of Whiteboard surface
- Fasten the Whiteboard Channel in place
 - Use two Bolt C's, Washer E's & Barrel Nut F's
 - Tighten fasteners


3



Bolt C


Washer E


Barrel Nut F



Attach Whiteboard


- Put Brakes in the locked/down position to hold the unit steady
- Align the holes in the Front Frame Assembly with the Rear Frame and the Front Frame Supports






Install Book Ledge

- Note: There are multiple locations on the side of the Whiteboard to install the Book Ledge. Choose the location that works the best for your classroom.
- Insert one hook into the appropriate hole on one side of the Whiteboard Frame
- Pull out opposite hook & snap into place Note: The spring tension is designed to discourage children from unhooking the Book Ledge









Place Tubs into Unit


- Angle the Tubs slightly when inserting into the Channel; tilt to fit over stop rib, and then slide into place
- In position, tubs will slide smoothly in the Channels & be stopped from sliding out unintentionally





Attach Chart Paper Hooks

- Place an empty hardware bag over the frame to prevent the unit from being scratched Hooks snap onto the frame easily
- Slide bag free once the Hook has been snapped onto the Frame





12	
*	

Validate Your Warranty & Enter to Win!



To validate your ten year frame warranty & lifetime tub warranty, submit the ON-LINE form at **www.copernicused.com**

User Name: *quality* Password: *safety#1*

Enter a draw to win a Copernicus Product for your classroom at the same time

I hope that the assembly of your **NEW Regal Reading Writing Center** went well.

If you have any questions, or concerns, please call us at 1-800-267-8494, where someone will be happy to help.

Enjoy using your new product, and happy teaching,

5 M

Jim Phillips President

"The beautiful thing about learning is that no one can take it away from you." - B. B.

