



Brentwood™



**Rapid
Loc™**
System

No. of Children: Up to 10
Min. Use Zone: 29' x 27'
Set Dim. 15'W x 13'L x 11'H
Est. Building Time: 5-10 hr.

ASSEMBLY INSTRUCTIONS

Safety Checklist for Play Sets and Accessories

Observing the following statements and warnings reduces the likelihood of serious or fatal injury

Installation Safety – Have You:

- Consulted the assembly instructions supplied with your particular model?
- Noted this accessory is to be used only on approved designs? (Do not alter its design or add/remove components.)
- Made sure all hardware is tightened securely? (Supplied bolt covers must also be fastened securely.)
- Using a hacksaw, cut off all protruding threaded ends of bolts and other fasteners and remove any sharp edges with a metal file as needed?
- Placed the equipment on level ground, not less than six feet (1.8 meters) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires?
- Made sure home playground equipment is not installed over concrete, asphalt, packed earth or any other hard surface? (A fall onto a hard surface can result in serious injury to the equipment user.)
- Verified that suspended climbing ropes, chain, or cable are secured at both ends?
- Consulted in assembly instructions of your particular model for minimum use zones?
- Followed all anchoring and shock absorbing surfacing requirements on the back of this sheet as they apply?
- Made sure not to allow children to use equipment until it is properly installed?

Operating Safety – Have You:

- Determined that on-site adult supervision is provided for children of all ages?
- Warned children the following before allowing them to use the equipment?
 - Not to walk close to, in front of, behind or between moving items.
 - Not to twist swing or any other accessory chains or ropes or loop them over the top support bar since this will reduce the strength of chain or rope.
 - Not to swing empty seats or other accessories.
 - Be sure to sit in the center of the swing seat and other accessories with full weight on the seat.
 - Not to attach items to the playground equipment that are not specifically designed for use with the equipment such as but not limited to, jump ropes, clotheslines, pet leashes, cables and chain. They may cause a strangulation hazard.
 - Not to use equipment in a manner other than intended.
 - Not to get off equipment while it is in motion.
 - Not to climb on the equipment when it is wet.
- Determined that only one child per planned occupant seat should be allowed on this set at one time.
- Determined children must be dressed appropriately for play. Avoid clothing with draw strings and loose fitting clothes which could become entangled or snagged on equipment.
- Determined that suspended climbing ropes, chain, or cable cannot be looped back upon itself.
- Read and understood the following warning regarding the use of two and four passenger lawn swings?

Warning: Lawn Swings are designed for use by children over two years of age. Use by children under the age of two can result in entrapment between the seats and back areas. **Never** place children in a rearward facing position or with legs between the seat and backrest because the child's body may pass through the opening causing entrapment of the child's head.

Safety Maintenance – Have You Determined to:

- Check all nuts and bolts twice monthly during the usage season for tightness and tighten as required? (It is particularly important that this procedure be followed at the beginning of each season.)
- To prevent the deterioration of materials, remove plastic swing seats and other plastic accessories and take indoors? (Do not use when the temperature drops below 0° F.)
- Oil all metallic moving parts monthly during usage period?
- Check all hardware and equipment for sharp edges twice monthly during usage season? (Replace when necessary. It is especially important to do this at the beginning of each new season.)
- Check swing seats, chains, ropes and cables monthly during usage season for evidence of deterioration? Severe rusting or excessive wear, especially near the top swing hanger or at the seat connection are evidence of chain deterioration. Cracks in the protective plastic sleeve or seat itself are also signs of deterioration. If any of these conditions exist, call 1-800-888-1232 to order replacement accessories.
- Sand rusted metal parts and repaint using non-lead based paint.

Disposal Instructions

When the equipment is taken out of service, it must be disassembled and disposed of in such a way that no unreasonable hazards will exist at the time the set is discarded.

**Important! Additional Safety Instructions for all Playground Equipment.
Save this instruction sheet in the event the manufacturer needs to be contacted.**

This product is intended for single family home/residential use only and not intended for use in any public setting. Placement in any public setting constitutes a misuse of this product.

IMPORTANT!

ADDITIONAL REQUIRED SAFETY INSTALLATION INSTRUCTIONS

According to ASTM requirements, all kits must be anchored to the ground and, if the unit has a climbing rope, the rope end must be anchored to the ground. If soil conditions permit stakes to be pulled out easily, cementing into ground is necessary.

- **To anchor the unit to the ground**, Follow the instructions included in this plan for applying Anchor-It devices to your unit, or use 2" x 4" x 18" (45mm x 95mm x 457mm) pressure-treated stakes. Pound stakes into ground at least 12" (305mm) at all inside corners of the posts (including A-frame legs and climbing unit posts). Attach with four (4) 16D (3-1/2") galvanized nails per stake into each 4" x 4" (95mm x 95mm) post.
- **If the unit has a climbing rope**, anchor the rope end.
- **Once the unit is completely assembled and before children are allowed to play on it, proper shock-absorbing surfacing material must be installed.** This may be accomplished by using loose-fill materials at a sufficient depth. The Consumer Product Safety Commission "Handbook for Public Playground Safety" lists the following materials and required depths that are sufficient for home/residential application. For fall height protection up to 9 ft. (2.742m) [recommended for Swing•N•Slide kits]:

LOOSE FILL MATERIAL

REQUIRED (UNCOMPRESSED) DEPTH¹ in. (mm)


Wood Mulch	9" (229mm)
Double Shredded Bark Mulch	9" (229mm)
Uniform Wood Chips	12" (305mm)
Fine Sand	12" (305mm)
Fine Gravel	12" (305mm)

¹These depths were derived from the CPSC Handbook. Swing•N•Slide has not done independent tests to determine these required depths.


When properly installed, shock absorbing material will completely cover the horizontal baseboards on climbing units. This protective surfacing must extend a **minimum** of 6 ft. (1.828m) in all directions from the perimeter of the equipment or from the outermost edges of any component. For example, a slide extending beyond the platform must have protective surfacing at least 6 ft. (1.828m) out from both sides as well as the end. For swings, the protective surface must extend **at least 14 ft. (6m)** out from **both** the back and front of the swing when the swing is in its rest position.

NOTES:


TOOLS REQUIRED




ELECTRIC DRILL




1/2" SOCKET & WRENCH




HAMMER




TAPE MEASURE




**SAFETY GLASSES
& DUST MASK**



PHILLIPS BIT




CARPENTER'S SQUARE




(32) 1-1/4" lag screw



(4) 5/16" Hex Head Lag Screws




(54) 2" lag screw



(8) Tarp Washers



(8) 3/4" panhead screws




(6) 5/16" flat washers




(8) 3/4" screws



(2) Loc-Nuts




(1) 3/8" DRILL BIT



(119) 1-1/4" screws




(3) 1-1/2" screws



(1) T20 Torx® Bit




(296) 2-1/2" screws




(1) T30 Torx® Bit



(6) 3" screws




(2) Wood Loc Washers



(2) 6-1/2" Bolts

Rapid Loc™ System




(8) Shelf-Loc




(2) Step Brackets


Note: (1 Left, 1 Right)




(2) 3X3 TO 4X4 Shelf-Loc




(6) Wrap-Loc




(2) Split Beam bracket




(2) EZ Frame Brackets



(1) Pleated Tarp



(1) Window Frame




(4) Anchor-It




(2) Play Handles with Hardware




(4) Anchor-It Straps




(1) Plan




(1) Name Plate




**(1) Coolwave Slide
with Hardware
250 lb Weight Limit**




**(1) Discovery Mountain
with Hardware
450 lb Weight Limit**




**(2) Reg Duty Swing Seat
with Hardware
115 lb Weight Limit**




**(8) Swing Hanger
with Hardware**



**(1) 2 For Fun
with Hardware
150 lb Weight Limit**



**(8) Climbing Rocks w/ Hardware
230 lb
Weight Limit**



**(1) Steering Wheel
With Hardware**


Brentwood Board List



(2) 2" x 4" x 5"



(3) 2" x 4" x 17-1/4" (Slide Stake)



(2) 2" x 4" x 22"



(2) 2" x 4" x 25-1/2"



(4) 2" x 4" x 36"



(1) 2" x 4" x 47"



(8) 2" x 4" x 47-1/2"



(1) 1" x 4" x 7-7/16" Window Top



(1) 1" x 4" x 7-3/4"



(1) 1" x 4" x 10" Window Sill



(2) 1" x 4" x 15-5/16" Shutters



(1) 1" x 4" x 18"



(3) 1" x 4" x 20-1/2"




(8) 1" x 4" x 24"




(8) 1" x 4" x 30"




(2) 1" x 4" x 30" Window Sides




(2) 1" x 4" x 41-1/4"




(7) 1" x 4" x 46"




(1) 1" x 4" x 46-3/4"




(23) 1" x 4" x 47-1/2"



(2) 5/4" x 4" x 20" Angle Brace




(1) 1" x 3" x 23-1/2"



(2) 3" x 3-1/2" x 94"



(4) 3" x 3" x 94" (Plastic Coated)



(1) 4" x 4" x 47-1/2"



(1) 4" x 6" x 94" Swing Beam

How to select the correct fastener


Use these 2 pictorial guides to help select the correct fastener(s) for the lumber attachment you are making. Each diagram will highlight the correct number of fasteners to use, and where to attach them.

1" x 4" to 3" x 3"



(3) 2-1/2" screws

Apply 2-1/2" screws to the 1"x4" boards when attaching to 3"x3" uprights.




1" x 4" to 1" x 4"




(2) 1-1/4" screws

Use 1-1/4" screws when mounting 1" x 4" boards to 1" x 4" boards.



Understanding how the Bracket System Works

Example of a Shelf-Loc bracket connection.





Wrap-Loc

Shelf-Loc Bracket


CORRECT!

WRONG!



Example of a Shelf-Loc bracket connection.


Look for "TOP" stamp on bracket for correct orientation.



Brackets Clip Together


DO NOT USE LAG SCREWS HERE
Use Lag Screws Only Where Brackets Attach





Introduction to the Bracket system

- 1. ALWAYS** Use 1-1/4" or 2" lag screws on all brackets.
- Brackets "clip" to each other. **NEVER** position in a non-interlocking position.

NOTE: PLACE SCREWS IN BRACKETS **ONLY WHERE INSTRUCTED. DO NOT FILL EVERY HOLE IN BRACKET.** THIS WILL LEAD TO HARDWARE SHORTAGES.



Frame 1 Construction



1-1/4" Lag screw





2" Lag screw

A. Frame 1 Construction

1. Measure and position brackets on 3" x 3" as shown in **(Fig.1a)**.

Note: Secure Shelf Lock with **(2) Lag Screws only** at this time.

•WARNING•
 Avoid splitting your
 lumber by offsetting
 your screws at least
 3/4" from edge.



**Double check to make
 sure structure is square**

Frame 1 Construction

Fig. 2

Tip: Flex brackets to make installation of
 2" x 4" easier




Fig. 2a










Fig. 2b




NOTE: Upper screws are (2) 1-1/4" Lag
 Screws, Lower screws are (3) 2" Lag
 Screws.



A. Frame 1 Construction cont.

2. Attach boards as shown in (Fig. 2) through (Fig. 2c).



Frame 2 Construction

Fig. 3






Fig. 3a



1-1/4" Lag screw

A. Frame 2 Construction


1. Measure and position brackets on 3" x 3" as shown in **(Fig.3)**.

Note: Secure Shelf Lock with **(2) Lag Screws only** at this time.




Frame 2 Construction

•WARNING•
Avoid splitting your lumber by offsetting your screws at least 3/4" from edge.




Fig. 4



Tip: Flex brackets to make installation of 2" x 4" easier






Double check to make sure structure is square



A. Frame 2 Construction cont.


2. Attach boards as shown in (Fig. 4) through (Fig. 4b).

Fig. 5




A. Frame Construction cont.

1. Attach 1"x4" and 2"x4" boards as shown.



1-1/4" Lag screw




2" Lag screw



2-1/2" screw

Fig. 6



Tip: Flex brackets to make installation of 2" x 4" easier





Fig. 6a

Fig. 6b




NOTE: Upper screws are (2) 1-1/4" Lag Screws, Lower screws are (3) 2" Lag Screws.


A. Frame Construction (cont.)

1. Attach Frame 2 to Frame 1 as shown.
Note: Outside to Outside measurement of uprights on all four sides of the tower should be 47-1/2".

1-1/4" Lag screw



2" Lag screw



1-1/4" screw



2-1/2" screw



Fig. 7







Fig. 7a



B. Install Deck Boards

1. Install (2) 1" x 4" deck boards as shown in **(Fig. 7)**.
2. Attach 2" x 4" to deck boards using 2-1/2" screws as shown in **(Fig. 7)**.
3. Attach 1" x 4" Slide Support as shown in **(Fig. 7a)**.

Fig. 8



NOTE: There must be a 1/2" Nominal Gap between all deck boards.

2-1/2" screw



B. Install Deck Boards

1. Install (10) 1" x 4" deck boards to structure as shown (**Fig. 8**).
2. Use two 2-1/2" screws at center and each end of deck boards.

Note: Screws at center will attach to center support.

Fig. 9





Fig. 9a



2-1/2" screw



C. Install Barrier Support Boards

1. Install (3) 1" x 4" lower Barrier Support Boards as shown in **(Fig. 9)**.
2. Install (3) 1" x 4" upper Barrier Support Boards as shown in **(Fig. 9a)**.

Tip: Flex brackets to make installation of 2" x 4" easier






Fig. 10a



ATTENTION:
Unit has been rotated
1/4 turn Counter
Clockwise for this view.


2" Lag screw



C. Install Lower Rail Boards

1. Install 4" x 4" Swing Beam Support as shown in (Fig. 10) and (Fig. 10a).


Fig. 11



D. Swing Beam Hole Locations

1. Install Swing Hangers into swing beam at locations shown.

Fig. 11a







E. Swing Beam Drill Locations

1. Tap T-nut into 3/8" hole as shown in **(Fig. 11a)**.
2. Place a bottom beam clamp over the swing hanger as shown in **(Fig. 11a)**.
3. Insert the swing hanger into the beam and thread it into the T-nut until it is flush or near flush with the top of the T-nut. A screwdriver may be used to twist the hanger **(Fig. 11a)**. Orient swing hanger as shown in **(Fig 11a)**.
4. Use (4) 1-1/4" screws to secure beam clamp.
5. Check hanger to ensure it does not spin.
6. Repeat for all four hangers.

Fig. 11b

**A-FRAME ATTACHES
HERE**



94"

1-1/2" → 27-1/4"
→ 25-3/4"

2 FOR FUN SWING
MOUNTS HERE

14"

1-1/2" → 11-3/4"
→ 10-1/4"


10-1/4"

Measure from Here

playset

- E. 2 For Fun Supports**
1. Along top of Swing Beam mark placement for 2 For Fun 2" x 4" Supports as shown in **(Fig. 11b)**.
 2. Position four beam brackets (right and left) in position on beam making certain the outside of the braces are 17" apart and the nailing edge of the bracket is flush with the top of the beam **(Fig. 11c)**. **Note:** 2 For Fun Beam Brackets must be placed a minimum of 8" from any adjacent structure or accessory **(Fig. 11d)**. Attach using three 2-1/2" screws per bracket.
 3. Drill two 2" x 4" x 22" supports as indicated in **(Fig. 11e)**. Attach four swing hangers to the supports using 5/16" flat washers and loc nuts as shown in **(Fig. 11f)**.
 4. Center supports across beam, mark and drill 3/8" holes **(Fig. 11c)**. Attach using two 2-1/4" Carriage bolts, 5/16" flat washers and loc nuts per bracket **(Fig. 11c)**.


Fig. 12



F. A-Frame Assembly

1. layout 3" x 3-1/2"s and 2" x 4" as shown in **(Fig. 12)**.
2. Align EZ Frame Bracket with face of 3" x 3-1/2"s.
3. Secure EZ Frame Bracket with (8) 2-1/2" screws to 3" x 3-1/2"s making sure they are flush with each other.
4. Secure 2" x 4" to 3" x 3-1/2"s as shown in **(Fig. 12a)**.
5. Flip over and add 2nd bracket. Repeat steps 2 and 3.


Fig. 12a



2-1/2" screw



Fig. 13



2-1/2" screw



G. A-Frame Assembly cont.

1. Align EZ-Frame Bracket with carriage bolts on Swing Beam as shown in **(Fig. 13)**.
2. Attach A-Frame beam to Swing Beam using (2) washers and (2) Loc-Nuts and 2 screws as shown in **(Fig. 13)**.
3. Tighten Loc-Nut. Repeat on other bracket.

Note: Examine all hardware after the loc-nuts are fully tightened. If more than two threads are exposed, cut the excess bolt off with a hacksaw or other suitable cutting tool.

H. A-Frame Assembly cont.

1. Position Split-Brackets on 4" x 4" x 47-1/2" (Fig 14).
2. With the help of others, lift A-Frame and Swing Beam Assembly and center onto unit as shown in (Fig. 14).
3. Secure as shown in (Fig 14a).







Fig. 15



Use 2-1/2" screws to secure to 1" x 4" to 4" x 4"

NOTE: There must be a 2-1/4" Nominal Gap between rear barrier boards.

Fig. 15a



(2)
1-1/4" deck screws per joint

NOTE: There must be a 2-1/4" Nominal Gap between side barrier boards.

1-1/4" screw




2-1/2" screw



I. Install Barriers

1. Attach (7) 1" x 4" Barrier Boards, evenly spaced as shown in **(Fig. 15)**.
2. Attach (3) 1" x 4" Barrier Boards, evenly spaced, as shown in **(Fig. 15a)**.


Fig. 16



J. Install Barriers

1. Attach (3) 1" x 4" Barrier Boards, evenly spaced as shown in **(Fig. 16)**.

Fig. 17



NOTE: There must be no Gap between front barrier boards. Mount Flush.

3/4" screw



1-1/4" screw



1-1/2" screw





K. Install Barrier

1. Attach 1" x 4" barrier boards as shown in (Fig. 17).
2. Install Window Frame, as shown in (Fig. 17a).

NOTE: You may need to readjust Window Top Board to properly align Window Frame with Opening.

Fig. 17a





2-1/2" screw



L. Climbing Wall Support

1. Install 2" x 4" Climbing Wall support board as shown in **(Fig. 18)**.

M. Climbing Wall.


1. Attach (8) 1" x 4" boards to (2) 2" x 4" boards and install on unit as shown in **(Fig. 19)**.

Note: There is a 2-3/4" Gap between each Climbing Wall 1" x 4" Board.

2. Attach Climbing Wall to unit as shown in **(Fig. 19a)**.

Fig. 19


TOP



(2)
2-1/2" screws
(Per joint)

NOTE:
5' Climbing Rock Wall will require
8 Climbing Rocks

Fig. 19b




M. Climbing Rock Installation

1. Mark locations of Climbing Rocks on the Climbing Wall in a pattern that will easily allow your child to climb to the deck. Make sure the bolt hole locations are clear of wall supports before drilling.
2. Drill holes through the wall at the desired locations using a 3/8" drill bit. Install Climbing Rocks as shown in **(Fig. 19b)**.
3. Make sure the Climbing Wall and Climbing Rock connections are secure before allowing any children to play on the Climbing Wall.


2-1/2" screw

Fig. 19a



(3)
2-1/2" screws
(Both Sides)

Fig. 20



1-1/2" screw




2-1/2" screw



N. Tarp Support Boards

1. Install 2" x 4" and 1" x 4" tarp support boards as shown in **(Fig. 20)**.

Fig. 20a



N. Install Canopy.

1. Install canopy as shown in **(Fig. 20a)**.
Note: Make certain pleats are facing outward when canopy is installed.
2. Secure canopy in six locations **(Fig. 20b)**.




Fig. 21





Fig. 21a




1-1/4" screw



2-1/2" screw

O. Install Protective Board and Window Dressing

1. Secure protective 1" x 4" barrier board as shown in **(Fig. 21)**.
2. Attach Window Sill and Shutters as shown in **(Fig. 21a)**.



P. Safety Handles.

1. Mount (2) safety handles in the Climbing Wall and Lookout Mountain openings, approximately 11" above the deck surface (**Fig. 22**).
2. Reference page 30 for Climbing Wall assembly and page 36 for Lookout Mountain assembly.

Fig. 23a






Fig. 23



1-1/4" screw



1" Truss Screw

Use truss head screws to secure slide to deck.

R. Slide Installation.

1. Attach Deck Support as shown in **(Fig. 23)**.
2. Install Slide centered in the provided opening as shown in **(Fig. 23a)**.
3. Attach Stake to end of slide as shown in **(Fig. 23b)**.

Fig. 23b




Fig. 24





Fig. 24a



Note: If stakes are not close enough to the wall to be secured, dig out the area around the stake(s) and reposition them until the wall and stakes meet. Fill in any ground removed and pack firmly.


2-1/2" screw



S. Lookout Mountain Attachment:

1. Assemble the wall support as illustrated in **(Fig. 24)**. Use three 2-1/2" screws to attach the 2" x 4" boards and two 2-1/2" screws per joint for the remaining assembly.
2. Place the top of the wall in front of the opening of the climbing unit. Center the top of the wall within the opening of the unit. **Note:** The edge of the wall should be firmly positioned against the climbing unit (**see Fig. 24a**). **Do not attach the wall at this time.**
3. Note the location of four holes in the sides of the wall (two each side). These holes will be used to secure the stakes and bracing. Mark the locations of these holes on the ground directly below the position of the holes on the wall. Remove the wall from the unit.
4. Dig four (4) holes approximately 12" below grade at the hole locations shown in **(Fig. 24a)**.
5. Pound the 18" stakes into the ground at the proper hole locations. Leave approximately 6" of each stake above grade. Level the grade around the stakes to assure the base of the wall is securely seated.

Fig. 24b



T. Lookout Mountain Attachment:

1. Reposition the wall in the opening of the climbing unit. Center the top of the wall in the opening of the unit. The edge of the wall should be firmly positioned against the climbing unit and the stakes should be inside the base of the wall. Secure the wall to the rail using four (4) 1" Truss Head screws as indicated in **(Fig. 24b)**. Secure the base to the stakes using one 1-1/4" panhead screw per joint.
2. Place the brace beneath the wall. Position the legs in the holes dug previously and adjust the brace until the brace lines up with the holes of the wall. Attach the wall to the brace using one 1-1/4" panhead screw per joint. Square the brace to the ground. **Note:** The bottom rail of the brace should rest firmly on the ground. Adjust the grade as required. Fill in each of the holes and level the surrounding grade.

Fig. 25





Fig. 25a




U. 2 FOR FUN SWING.

1. Place Bolt Covers over the top of the swing hangers and loc nuts. Secure to the supports using 2-1/2" screws per Bolt Cover, as shown in **(Fig. 25)**.
2. Thread chains through 2 for Fun handles as shown in **(Fig. 25a)**.
3. Attach handle assembly to seat using (1) 6 1/2" hex head bolts, (1) 5/16" loc washer, (2) 5/16" washers, and (1) 5/16" loc nut. Locate hardware as shown in **(Fig. 25a)**. Repeat this for the other side.
NOTE: Do not overtighten bolts. The bolt threads should not extend beyond the end of loc nut. Overtightening can damage the 2 For Fun Glider assembly and cause injury. Check this connection frequently to see if the Loc Nut stays in position. If there is any problem keeping the loc nut in position. Replace it immediately.
4. Attach 2 for FUN Glider to set. Crimp all swing hangers and clamps tightly.

Steering Wheel

Fig. 25b




V. Steering Wheel Installation.

1. Choose a desired location for the steering wheel and drill a 3/8" diameter hole through the lumber. **NOTE:** If lumber is greater than 2" in depth, you will need to counterbore the hole appropriately.
2. Mount steering wheel to climbing unit as indicated in (Fig. 25b).
3. Snap steering wheel cap into place (Fig. 25b).

Anchor-It

Fig. 25c



W. Anchor-It Installation.

Instructions for Anchoring Swing•N•Slide Activity Centers

1. Determine the final location of your activity center.
2. Place the Anchor-It stakes adjacent to the base and near the corners of your activity center (at the bottom of the legs on swing sets) and twist the auger-style stakes into the ground until only the loop is exposed.
3. Place the metal strap through the loop of the Anchor-It stake and secure it to the unit with a lag screw and washer as illustrated to the right. Note: Attach the strap to the unit with as little play as possible using whatever holes in the strap that work best.